





















































Universal Standard ATF Adapter Hose Chart

Part #	Hose #	Photo	M/F	Vehicle Description
941802	# 52		M	Chrysler with 5/8" Diameter Lines Dodge 1500 Series Truck (5.9L)
941801	# 51		F	
941817	# 67		M	Chrysler, Ford Aerostar, Jaguar, Mercedes, & Cadillac
941816	# 66		F	
941815	# 65		M	Jeep Cherokee, Ford Escort
941825	# 75		F	
941835	# 87		M	Dodge Durango/Dakota
941836	# 88		F	
941803	# 53		M	General Motors with 3/8" Tube Diameter Lines Ford F-150 (5.4L), Fusion, Contour
941807	# 57		F	
941820	# 70		M	General Motors with 5/16" Tube Diameter Lines Ford Expedition
941821	# 71		F	
942163S	GM Adapter		M	GM w/ Quick Disconnect (942162 - Blue Quick Disconnect Tool) Dodge Charger [Adapter mates with Hose #66]
941805	# 55		F	
940329	3/8" Adapter		M	Ford Windstar, Freestar, Focus, F-150 [Adapter mates with Hose #66]
941805	# 55		F	
940334	5/16" Adapter		M	Lincoln Continental, Ford Taurus [Adapter mates with Hose #66]
941813	# 63		F	
941818	# 68		M	Ford with Large Nut Adapter
941819	# 69		F	
941823	# 73		M	Ford with 5/16" Small/Long Nut Adapter
941822	# 72		F	
940875	# 79		M	Ford Escort
940874	# 78		F	
941923	1/2" Adapter		M	Ford F-150 (2009) [Adapter mates with Hose #66]
941809	#59		F	
941925	3/8" Adapter		M	Ford Focus (2006+) [Adapter mates with Hose #66]
941805	#55		F	

Universal Standard ATF Adapter Hose Chart

Part #	Hose #	Photo	M/F	Vehicle Description
941828	# 80		M	Import
941829	# 81		F	
941830	# 82		M	Infiniti, Lexus, and BMW
941813	# 63		F	
941831	# 83		M	Toyota, Nissan, Honda, Ford and Chrysler
941805	# 55		F	
941832	# 84		M	Toyota, Nissan & Honda
941809	# 59		F	
941841	# 89		M	Chevy Duramax w/ Allison Transmission (5.4L V-8 & Smaller)
941842	# 90		F	
941960	# 91		M	Ford F-250 & F-350 (Powerstroke & Gasoline w/ Torqueshift Transmission)
941961	# 92		F	
941080	# 93		M	Ford Focus / Mercury Mystique
941081	# 94		F	
941899	5/8" Adapter		M	Chevy Duramax w/ Allison Transmission (6.0L V-8 & Larger) [Adapter mates with Hose #51]
941900	# 149		F	
940388	# 124		M	
940389	# 142		F	
940328	1/2" Adapter		M	Ford F-250, 350, 450 & Excursion [Adapter + Hose #66] Dodge Truck V6 & V8, Jeep Grand Cherokee
941809	# 59		F	
941910	3/8" Adapter		M	Ford F-150, Explorer, Edge; Cadillac STS (2006) [Adapter mates with Hose #66]
941805	# 55		F	
942169	5/8" Adapter		M	GM 3/4 & 1 Ton w/ Allison Transmission (2002 & Newer) Dodge 2500 [Adapter mates with Hose #51]
941900	# 149		F	